


Searching and Recording Footage to a USB Version 4 Firmware

- Right click on screen to bring up login screen, select user from drop down box and enter password.



- Select Playback, 2nd icon on menu bar at top of screen.



- Select Camera from list of cameras on left hand side of the screen.
- Select Date from calendar on left hand side of the screen just below the camera list. Double click on date, footage should begin to play from the earliest time of that day.
- There is a Scroll Bar at the bottom of the live footage representing 24hrs of the selected date.
- You can use the Scroll Bar to help find a certain time in the day and find the required footage.

- Insert a USB stick at this stage.



- After you have found the footage you wish to save click the scissors icon at the bottom of the screen, labelled 'Clip'. Another icon will appear next to the scissors 'Clip Time', you can use this to specify a start and end time and select 'Export' from that screen.
- The recorder should find the USB stick to record to, you can create a folder if you wish and label the export or just save it directly on the USB with the channel and timestamp as the file name. By default MP4 is selected, can change to AVI if you wish. Press 'OK' and export should begin.
- You can check the progress of the export by clicking the 'Backup' icon on the very top right of the screen, 2nd icon in. If remaining size/MB is 0 then you can remove the USB.
- Click 'Live View' icon from menu bar to return to live view of cameras.
- Remove USB from recorder. The footage and an appropriate player should be on the USB ready to be viewed on any PC (Windows or MAC).

When viewing footage on PC it is important to open the Player first, then open the files from within the player.